Wireless Display



) Install RF Modem

1

3

5

Mount RF modem to inside of control box. Connect antenna cable, wireless display cable and power supply.



Install Antenna

Mount antenna on top of the control box and connect antenna cable.





Install RAM Mount

Option 2: Optional Flat Base Plate Useful for mounting with U-brackets





Quick Installation Guide







See the iBOS® Pro Installation Manual for more detailed instructions.



© 2016 Philadelphia Scientific LLC. All Rights Reserved. US & International Patents Pending.

DOC0009

Rev2 January, 2016